





music GmbH, Gewerbering 31, 8398 Pocking/W. Germany

Chorus


Eingangsstufe Normalkanal für CHORUS, 140





Schaltung Ansteuerung CHORUS



Alle Dioden 1N4148









Alle Dioden 1N4148

Netzteil für CHORUS 140



The diagram shows a power supply circuit. It starts with a 1820 ohm resistor in series with a 0.1 100V capacitor. This is followed by an 18K resistor and a 33 ohm resistor. A 4.70pF capacitor is connected to ground. The circuit then features a BD239C transistor and a 1N 4004 diode.



Schaltung Hall für CHORUS

